

# GPIO

BPI-R2-GPIO

## pin-define



2nd function	main function	pin#	xxxxxxxxxxxxxxxxxxxxxx	pin#	main function	2nd function
	+3V3	1		1	○	2
GPIO 56 #	I2C1_SDA	3		3	○	4
GPIO 55 #	I2C1_SCL	5		5	○	6
GPIO101	PWM 7	7		7	○	8
	GND	9		9	●	10
GPIO 51 #	PWM1 / UART1-TX	11		11	○	12
GPIO 52 #	PWM2 / UART1-RX	13		13	○	14
GPIO 98 #		15		15	○	16
	+3V3	17		17	○	18
GPIO 68 #	PWM5 / SPI1 MOSI	19		19	○	20
GPIO 69	PWM6 / SPI1 MISO	21		21	○	22
GPIO 67	PWM4 / SPI1 CLK	23		23	○	24
	GND	25		25	○	26
GPIO 58	I2C2 SDA	27		27	○	28
GPIO 85		29		29	○	30
GPIO 82	SPI0 MOSI	31		31	○	32
		33		33	○	34
		35		35	○	36
GPIO 86		37		37	○	38
	GND	39		39	●	40

(# verified gpio working, 101 is blocked by pwm)

- uart0 (dts) ⇒ Debug-Uart
- uart1 (dts) ⇒ undefined ⇒ mt7622\_uart2\_2\_tx\_rx\_pins (59/60)
- uart2 (dts) ⇒ uart1 (gpio) ⇒ mt7622\_uart2\_1\_tx\_rx\_pins (51/52)

## Kernel 4.19

```
root@bpi-iot-ros-ai:~# cat /sys/kernel/debug/pinctrl/10211000.pinctrl-
pinctrl_mt7622/gpio-ranges
GPIO ranges handled:
0: pinctrl_mt7622 GPIOS [409 - 511] PINS [0 - 102]
root@bpi-iot-ros-ai:~# GPIO_N0=$((409+56))
root@bpi-iot-ros-ai:~# echo $GPIO_N0
465
root@bpi-iot-ros-ai:~# echo $GPIO_N0 > /sys/class/gpio/export
-bash: echo: write error: Invalid argument => blocked by i2c1

#if i2c1 is disabled in dts:
root@bpi-r64:~# echo $GPIO_N0 > /sys/class/gpio/export
root@bpi-r64:~# echo out > /sys/class/gpio/gpio${GPIO_N0}/direction
root@bpi-r64:~# echo 1 > /sys/class/gpio/gpio${GPIO_N0}/value #led goes on
root@bpi-r64:~# echo 0 > /sys/class/gpio/gpio${GPIO_N0}/value #led goes off
```

The sysfs interface (/sys/class/gpio/...) needs kernel-option CONFIG\_GPIO\_SYSFS

## uart

debug-Uart is uart0 in DTS, uart2 seems to be uart1 of gpio header...uart1 is currently not defined in dts.

## on-board LEDs

needs LEDS\_GPIO [=y]

there is only red and green, red seems not working

```
echo 1 > /sys/class/leds/bpi-r64\:pio\:green/brightness
```

## pwm

in linux numbering begins at 0 where on bpi documentation/gpio-header pwms starting at 1...

- pwm1 pin 11 (GPIO 51)
- pwm2 pin 13 (GPIO 52)
- pwm3 fan,inverted - seems not working correctly
- pwm4 pin 23 (GPIO 67)
- pwm5 pin 19 (GPIO 68)
- pwm6 pin 21 (GPIO 69)
- pwm7 pin7 (GPIO101) - seems not working

pwm working except 3 (2) and 7 (6) in my 5.7-pwm branch

```
root@bpi-r64:~# cd /sys/class/pwm/pwmchip0
root@bpi-r64:/sys/class/pwm/pwmchip0# echo 0 > export
root@bpi-r64:/sys/class/pwm/pwmchip0# cd pwm0
root@bpi-r64:/sys/class/pwm/pwmchip0/pwm0# echo 10000 > period
root@bpi-r64:/sys/class/pwm/pwmchip0/pwm0# echo 5000 > duty_cycle
root@bpi-r64:/sys/class/pwm/pwmchip0/pwm0# echo 1 > enable
```

## pwm in uboot

pwm-patches from sam are merged in 2020-07, but to use them there is cmd\_pwm needed

<http://forum.banana-pi.org/t/bpi-r64-current-u-boot-support/10077/74>

both Available in 2020-04-bpi-pwm branch

here pwm1 (0) is defined in dts

From:  
<https://wiki.fw-web.de/> - **FW-WEB Wiki**

Permanent link:  
<https://wiki.fw-web.de/doku.php?id=en:bpi-r64:gpio>



Last update: **2023/06/08 17:06**