

Hardware-NAT

- available in LEDE [forum](#)
- seems to work with 4.14, Test: <https://github.com/frank-w/BPI-R2-4.14/tree/4.14-hnat> [forum](#)
- no support in 4.4.70 [forum](#)

Current implementation works only between lan and wan (not wifi or other interfaces)

Check if it is working with

```
#via debugfs (working shows BIND-state)
cat /sys/kernel/debug/hnat/all_entry
#via interrupts (counter does not increase after a while (download))
cat /proc/interrupts | grep 'ethernet'
```

[original-Patch for 4.9 \(lede\)](#)

From:
<https://wiki.fw-web.de/> - **FW-WEB -Wiki**

Permanent link:
<https://wiki.fw-web.de/doku.php?id=en:bpi-r2:hwnat&rev=1532029137>

Last update: **2020/08/29 17:14**

